



1. Cut the above template out and mount inside your transparent box using blu-tack.

See <http://www.oneswitch.org.uk/4/DIY/SUGRU-A-PAC.htm> for full details.

Soldering-Free D.I.Y. Switch Interface

Public Domain

Idea by Barrie Ellis of SpecialEffect and OneSwitch.org.uk